


Bottom view



Front view

Optional attachment 1

Optional side attachment 2

Isometric view
Scale: 3:4

Assembly:

- 1. Attach lenses by pressing them down until they snap into place.
- 2. Screw the holder (with lenses assembled) to PCB. Inspect that the positioning pins are securely in their holes.
- 3. Press the shade down on the holder until they are securely attached.

Optional side attachment: The holder can also be attached with DIN 7985 M3 nuts


- 1. One nut per side for rotational attachment
- 2. Two per side for fixed beam direction

Recommendations:

Screw type DIN 7985 M3, max. torque 0.6Nm

INDEX	PART NO	DESCRIPTION	MATERIAL	COLOUR
1	C15028	FLORENTINA-4X1-SHD	PC	black
2	C15029	FLORENTINA-4X1-HLD	PC	black
3	-	CMC / MRK lenses		

Tolerances if not otherwise shown
According to DIN ISO 2768-1
Linear measures:
up to 30mm class M, otherwise class C
According to DIN ISO 2768-2
Form and position: class L



This drawing is the property
of LEDiL Oy. It may not be
reproduced, copied or
communicated without a written
agreement with LEDiL Oy.

<div>LEDiL</div> <div>Ledil Oy Salorankatu 10 FIN 24240 SALO Finland</div>		DRAWING TITLE			
		FLORENTINA-4x1 assembly			
SIZE	PART NUMBER				
A3	-				
SCALE	1:1	WEIGHT	58 g		SHEET 1/1